Installation Instructions

Instruction

The door hooks are mounted on the inside of the drying cabinet door and fit all cabinets in the ProLine series. See mounting suggestion below.



01/2025 Product no. 131071

 Incorrect installation may damage the door or cause the hooks to detach under load.
 Ensure that the screws are properly tightened and that the door can support the chosen placement.

Do not overload the hooks.
This product is intended for installation only inside drying cabinets in the ProLine series.

Installation

- 1. Choose the desired position on the inside of the door. See mounting suggestion below for the recommended placement.
- 2. Pre-drill holes using a 4 mm (5/32") drill bit.
- 3. Fasten the door hooks using the included sheet metal screws.
- 4. Make sure the hooks are securely mounted before use.

TS 63 E/TS 63 VP





TS 93 E/FC 20