

INSTRUCTIONS

Drying cabinet BaseLine TS 4 E

Dry



1. Open the door



2. Pull out the rails and hang the laundry



3. Close the door



4. Start the display

Click 'ON/OFF', green light indicates the drying cabinet is on.



5a. Automatic programs

Choose automatic programs with temperature '40°' or '60°'.




5b. Timed drying

Choose temperature with 'MAN'. Set drying time by clicking '+' or '-'.



6. Start the drying

Click on 'START/STOP'.



7. Unload the laundry

When the program is finished the display shows 'END'.

Extra



Abort

Click on 'START/STOP' to abort a program.



Pause

Open the door to pause a program.