Drain through 24/42/70 L

INSTALLATION MANUAL

Components

- 1 pc drain through
- 1 pc cleaning grate

10/2025
Article No. 161032, 161000, 161002

- The product is only intended for washing machines.
- Incorrect installation may result in water leakage.
- Follow the care instructions.
- Keep the instructions with the product.

Installation

1. Place the drain through with the cleaning grate in position behind the washing machine with the outlet facing the drain.
2. Make sure there is enough space for the user to access the drain through when cleaning the grate.
3. Check with a spirit level that the drain through has a slight slope towards the drain outlet. Adjust if necessary by placing a spacer under the drain through at the opposite end (spacer not included).
4. Direct the drain water from the washing machine into the drain through using a pipe elbow.
5. Install a drain pipe from the drain through and lead it with a fall to the drain.
6. Test run the washing machine and fast-forward to the emptying phase. Check that the washing machine empties the water into the drain through without splashing or spill at the sides. Also check that the pipes and connections are tight all the way to the drain.

Care instructions

- Clean the grate daily. Use warm water, mild detergent, and a dish brush/scrub brush. Avoid steel brushes.
- Remove debris and foreign objects from the bottom of the drain through as needed. Do not leave metal objects in the gutter for long periods of time, as they may rust and damage the surface material.
- Clean the outside of the drain through with a damp cloth and mild detergent.
- Check the function, slope towards the drain, and condition of the pipe fittings annually.

Copyright © 2025 PODAB. All rights reserved.
We reserve the right to make changes without prior notice.

Additional documents and information about your product can be found at **www.podab.com.**